

## ORP57 PRO



PRO ORP / Temperature Meter with replaceable electrode

Rating: Not Rated Yet  
[Ask a question about this product](#)

Description

**ORP57 PRO Pocket-size ORP / Temperature Meter with replaceable electrode**

IP65 Waterproof pH tester with Large dual-level LCD that displays ORP and temperature (°C or °F). The large display shows readings from -1000 to +1000 (with a resolution of 1 mV) and simultaneously shows temperature from -5.0 to 105.0°C or 23.0 to 221.0°F. ORP57 has a stability indicator and hold function that freezes the display for easy and accurate recording.

The large display also has graphic symbols to guide you through all operations. Complete with a temperature probe for faster and more precise temperature measurement it compensates automatically for temperature. Auto power OFF saves battery power after non-use. The double-junction electrode can be replaced in a very fast and simple way! The modular design allows easy electrode and battery replacement.

Specification	ORP57
Range	ORP ±1000 mV Temp -5.0 to 60.0°C / 23.0 to 140.0°F
Resolution	ORP 1 mV Temp 0.1°C / 0.1°F
Accuracy	ORP ±2 mV Temp ±0.5°C / ±1°F
EMC Typical Deviation	ORP ±2 mV Temp ±0.3°C / ±0.6°F
Calibration	factory calibrated
Probe	Mi57P (replaceable)
Environment	0 to 50°C, 100% RH
Battery Type	4 x 1.5V; IEC LR44, A76; alkaline
Battery Life	approx. 300 hours of continuous use
Auto-off	after 5 minutes of non-use
Packaging dimensions / weight	254 x 67 x 47 mm / 140 g

**Accessories:**

- **Mi57P** Replaceable electrode for ORP57
- **MA9015** Electrode storage solution, 230 mL
- **MA9016** Electrode cleaning solution, 230 mL
- **MA9020** ORP test solution (200/275 mV), 230 mL bottle
- **M10000B** Electrode rinse solution, 20 mL (25 pcs)

**Ordering information:**

ORP57 is supplied complete with protective cap, carton box, batteries and instructions.