

## MW600 PRO



PRO Portable Dissolved Oxygen Meter

Rating: Not Rated Yet

[Ask a question about this product](#)

### Description

#### **MW600 PRO Portable Dissolved Oxygen Meter**

The MW600 is a Portable Dissolved Oxygen meter ideal for use in school laboratories. Dissolved Oxygen measurements are also very important in fish farms and ponds, where Oxygen levels are continuously monitored to obtain optimal reproduction.

The MW600 calibrates easily in 2 points (at 100% saturated air and in 0 Oxygen solution) and has Automatic Temperature Compensation which guarantees the highest accuracy. The low battery warning, easy to replace screw on cap membranes make this meter very simple to operate. Rugged Carrying Case (Optional) provides handy on-site meter calibration and measurements.

MW600 is supplied complete with a MA840 D.O. polarographic probe with 3 m cable, calibration screwdriver, 2 spare membranes, MA7040 (20 mL) electrolyte solution, battery and instructions.

# Dissolved Oxygen: MW600 PRO

---

Specification	MW600
Range	0.0 to 19.9 mg/l
Resolution	0.1 mg/L
Accuracy (@25°C)	±1.5% full scale
Calibration	manual on 2 points (zero and slope)
Temperature Compensation	automatic, from 0 to 30°C
Probe	MA840 (included)
Environment	0 to 50°C / 32 to 122°F; max RH 95%
Battery Type	1 x 9V alkaline (included)
Battery Life	approximately 70 hours of continuous use
Packaging dimensions / weight	268 x 122 x 118 mm / 880 g

## Accessories:

- **MA9070** Zero Oxygen Solution, 230 ml bottle
- **MA9071** Refilling Electrolyte Solution, 230 ml bottle
- **MA840** Polarographic D.O. probe with 3 meters cable
- **MA841** Spare membrane (5 pcs)

## Ordering information:

MW600 is supplied complete with MA840 probe, 2 spare membranes, 20 mL bottle of electrolyte solution, calibration screwdriver, 9V battery and instructions.