

## EC60 PRO



PRO Conductivity / TDS / Temperature Meter with replaceable electrode

Rating: Not Rated Yet  
[Ask a question about this product](#)

Description

**EC60 PRO Pocket-size Conductivity / TDS / Temperature Meter with replaceable electrode**

This new waterproof Pocket-size EC/TDS/Temp Meter include features such as a replaceable probe, temperature in °C or °F, automatic temperature compensation with adjustable  $\beta$ , battery level indicator, stability indicator, automatic shut-off and automatic calibration all in a floating, waterproof casing.

EC60 shows on the dual-level LCD the EC (20.00 mS/cm) or TDS (10.00 ppt) value. It also displays the temperature from 0.0 to 60.0°C (or 32.0 to 140.0°F) on the secondary level at the same time.

Specification	EC60
Range	EC 20 mS/cm
	TDS 10.00 ppt
	Temp 0.0 to 60.0°C / 32.0 to 140.0°F
Resolution	EC 0.01 mS/cm
	TDS 0.01 ppt
	Temp 0.1°C / 0.1°F
Accuracy	EC $\pm 2\%$ Full Scale
	TDS $\pm 2\%$ Full Scale
	Temp $\pm 0.5^\circ\text{C} / \pm 1^\circ\text{F}$
EMC Typical Deviation	EC $\pm 2\%$ Full Scale
	TDS $\pm 2\%$ Full Scale
	Temp $\pm 0.5^\circ\text{C} / \pm 1^\circ\text{F}$
Calibration	automatic, 1 point
Temperature compensation	automatic with $\beta=0.0$ to $2.4\%/^\circ\text{C}$
Probe	Mi59P (replaceable)
Environment	0 to 50°C, 100% max. RH
Battery Type	4 x 1.5V, EC LR44, A76; alkaline
Battery Life	approx. 100 hours of continuous use
Auto-off	after 8 minutes of non-use
Packaging dimensions / weight	254 x 67 x 47 mm / 180 g

**Accessories:**

- **Mi59P** Replaceable probe for EC59 & EC60
- **M10030B** 12880  $\mu\text{S}/\text{cm}$  calibration solution, 20 mL sachet, 25 pcs.
- **MA9060** 12880  $\mu\text{S}/\text{cm}$  calibration solution, 230 mL bottle

**Ordering information:**

EC60 is supplied complete with protective cap, 20 mL 12880  $\mu\text{S}/\text{cm}$  sachet of calibration solution, batteries and instructions in a plastic tube.